



[B-1 1 Gang 1 Way switch-Grey](#)



[B-1 1 Gang 2 Way switch-Grey](#)



[B-1 2 Gang 1 Way switch-Grey](#)



[B-1 2 Gang 2 Way switch-Grey](#)



[B-1 3 Gang 1 Way switch-Grey](#)



[B-1 3 Gang 2 Way switch-Grey](#)



[B-1 4 Gang 1 Way switch-Grey](#)



[B-1 4 Gang 2 Way switch-Grey](#)



[B-1 Doorbell switch-Grey](#)



[B-1 20A switch-Grey](#)



[B-1 45A switch-Grey](#)



[B-1 Universal 3 Pin Socket With Switch With Indicator Light-Grey](#)



[B-1 UK Socket With Switch With Indicator Light-Grey](#)



[B-1 French socket-Grey](#)



[B-1 German socket-Grey](#)



[B-1 Telephone Socket-Grey](#)



[B-1 Network Socket-Grey](#)



[B-1 Satellite Socket-Grey](#)



[B-1 Double Universal 3 Pin Socket With Switch With Indicator Light-Grey](#)



[B-1 Double UK Socket With Switch With Indicator Light-Grey](#)